



## QUADRA-CHEK 3000 – Listed Printer (CUPS 1.5)

Firmware version 826880.1.0.0 or higher

Producer	Model
Apollo	Apollo P-2100 - CUPS+Gutenprint v5.2.10
Apollo	Apollo P-2150 - CUPS+Gutenprint v5.2.10
Apollo	Apollo P-2200 - CUPS+Gutenprint v5.2.10
Apollo	Apollo P-2250 - CUPS+Gutenprint v5.2.10
Apollo	Apollo P-2500 - CUPS+Gutenprint v5.2.10
Apollo	Apollo P-2550 - CUPS+Gutenprint v5.2.10
Apollo	Apollo P-2600 - CUPS+Gutenprint v5.2.10
Apollo	Apollo P-2650 - CUPS+Gutenprint v5.2.10
Apple	Apple Color StyleWriter 4100 - CUPS+Gutenprint v5.2.10
Apple	Apple Color StyleWriter 4500 - CUPS+Gutenprint v5.2.10
Apple	Apple Color StyleWriter 6500 - CUPS+Gutenprint v5.2.10
Apple	Apple LaserWriter Select 360 - CUPS+Gutenprint v5.2.10
Brother	Brother DCP-1200 - CUPS+Gutenprint v5.2.10
Brother	Brother DCP-8045D - CUPS+Gutenprint v5.2.10
Brother	Brother HL-4Ve - CUPS+Gutenprint v5.2.10
Brother	Brother HL-10h - CUPS+Gutenprint v5.2.10
Brother	Brother HL-10V - CUPS+Gutenprint v5.2.10
Brother	Brother HL-630 - CUPS+Gutenprint v5.2.10
Brother	Brother HL-660 - CUPS+Gutenprint v5.2.10
Brother	Brother HL-760 - CUPS+Gutenprint v5.2.10
Brother	Brother HL-960 - CUPS+Gutenprint v5.2.10
Brother	Brother HL-1040 - CUPS+Gutenprint v5.2.10
Brother	Brother HL-1050 - CUPS+Gutenprint v5.2.10
Brother	Brother HL-1060 - CUPS+Gutenprint v5.2.10
Brother	Brother HL-1070 - CUPS+Gutenprint v5.2.10
Brother	Brother HL-1240 - CUPS+Gutenprint v5.2.10
Brother	Brother HL-1250 - CUPS+Gutenprint v5.2.10
Brother	Brother HL-1260 - CUPS+Gutenprint v5.2.10
Brother	Brother HL-1270N - CUPS+Gutenprint v5.2.10
Brother	Brother HL-1430 - CUPS+Gutenprint v5.2.10
Brother	Brother HL-1440 - CUPS+Gutenprint v5.2.10

Producer	Model
Brother	Brother HL-1450 - CUPS+Gutenprint v5.2.10
Brother	Brother HL-1470N - CUPS+Gutenprint v5.2.10
Brother	Brother HL-1650 - CUPS+Gutenprint v5.2.10
Brother	Brother HL-1660e - CUPS+Gutenprint v5.2.10
Brother	Brother HL-1670N - CUPS+Gutenprint v5.2.10
Brother	Brother HL-1850 - CUPS+Gutenprint v5.2.10
Brother	Brother HL-1870N - CUPS+Gutenprint v5.2.10
Brother	Brother HL-2030 - CUPS+Gutenprint v5.2.10
Brother	Brother HL-2035 - CUPS+Gutenprint v5.2.10
Brother	Brother HL-2060 - CUPS+Gutenprint v5.2.10
Brother	Brother HL-2460 - CUPS+Gutenprint v5.2.10
Brother	Brother HL-2460N - CUPS+Gutenprint v5.2.10
Brother	Brother HL-5030 - CUPS+Gutenprint v5.2.10
Brother	Brother HL-5040 - CUPS+Gutenprint v5.2.10
Brother	Brother HL-5050 - CUPS+Gutenprint v5.2.10
Brother	Brother HL-5070N - CUPS+Gutenprint v5.2.10
Brother	Brother HL-5140 - CUPS+Gutenprint v5.2.10
Brother	Brother HL-5150D - CUPS+Gutenprint v5.2.10
Brother	Brother HL-5170DN - CUPS+Gutenprint v5.2.10
Brother	Brother HL-7050 - CUPS+Gutenprint v5.2.10
Brother	Brother HL-7050N - CUPS+Gutenprint v5.2.10
Brother	Brother MFC-6550MC - CUPS+Gutenprint v5.2.10
Brother	Brother MFC-8300 - CUPS+Gutenprint v5.2.10
Brother	Brother MFC-9500 - CUPS+Gutenprint v5.2.10
Brother	Brother MFC-9600 - CUPS+Gutenprint v5.2.10
Canon	Canon 50i - CUPS+Gutenprint v5.2.10
Canon	Canon 80i - CUPS+Gutenprint v5.2.10
Canon	Canon 450i - CUPS+Gutenprint v5.2.10
Canon	Canon 455i - CUPS+Gutenprint v5.2.10
Canon	Canon 470PD - CUPS+Gutenprint v5.2.10
Canon	Canon 475PD - CUPS+Gutenprint v5.2.10
Canon	Canon 550i - CUPS+Gutenprint v5.2.10
Canon	Canon 560i - CUPS+Gutenprint v5.2.10
Canon	Canon 850i - CUPS+Gutenprint v5.2.10
Canon	Canon 860i - CUPS+Gutenprint v5.2.10
Canon	Canon 865R - CUPS+Gutenprint v5.2.10
Canon	Canon 900PD - CUPS+Gutenprint v5.2.10
Canon	Canon 950i - CUPS+Gutenprint v5.2.10
Canon	Canon 960i - CUPS+Gutenprint v5.2.10
Canon	Canon 990i - CUPS+Gutenprint v5.2.10
Canon	Canon 6100i - CUPS+Gutenprint v5.2.10
Canon	Canon 6500i - CUPS+Gutenprint v5.2.10
Canon	Canon 9100i - CUPS+Gutenprint v5.2.10
Canon	Canon 9900i - CUPS+Gutenprint v5.2.10
Canon	Canon BJ-30 - CUPS+Gutenprint v5.2.10
Canon	Canon BJC-50 - CUPS+Gutenprint v5.2.10

Producer	Model
Canon	Canon BJC-55 - CUPS+Gutenprint v5.2.10
Canon	Canon BJC-80 - CUPS+Gutenprint v5.2.10
Canon	Canon BJC-85 - CUPS+Gutenprint v5.2.10
Canon	Canon BJC-210 - CUPS+Gutenprint v5.2.10
Canon	Canon BJC-240 - CUPS+Gutenprint v5.2.10
Canon	Canon BJC-250 - CUPS+Gutenprint v5.2.10
Canon	Canon BJC-1000 - CUPS+Gutenprint v5.2.10
Canon	Canon BJC-2000 - CUPS+Gutenprint v5.2.10
Canon	Canon BJC-2010 - CUPS+Gutenprint v5.2.10
Canon	Canon BJC-2100 - CUPS+Gutenprint v5.2.10
Canon	Canon BJC-2110 - CUPS+Gutenprint v5.2.10
Canon	Canon BJC-3000 - CUPS+Gutenprint v5.2.10
Canon	Canon BJC-4000 - CUPS+Gutenprint v5.2.10
Canon	Canon BJC-4300 - CUPS+Gutenprint v5.2.10
Canon	Canon BJC-4400 - CUPS+Gutenprint v5.2.10
Canon	Canon BJC-4550 - CUPS+Gutenprint v5.2.10
Canon	Canon BJC-5100 - CUPS+Gutenprint v5.2.10
Canon	Canon BJC-5500 - CUPS+Gutenprint v5.2.10
Canon	Canon BJC-5500J - CUPS+Gutenprint v5.2.10
Canon	Canon BJC-6000 - CUPS+Gutenprint v5.2.10
Canon	Canon BJC-6100 - CUPS+Gutenprint v5.2.10
Canon	Canon BJC-6200 - CUPS+Gutenprint v5.2.10
Canon	Canon BJC-6500 - CUPS+Gutenprint v5.2.10
Canon	Canon BJC-7000 - CUPS+Gutenprint v5.2.10
Canon	Canon BJC-7100 - CUPS+Gutenprint v5.2.10
Canon	Canon BJC-8200 - CUPS+Gutenprint v5.2.10
Canon	Canon BJC-8500 - CUPS+Gutenprint v5.2.10
Canon	Canon CP-10 - CUPS+Gutenprint v5.2.10
Canon	Canon CP-100 - CUPS+Gutenprint v5.2.10
Canon	Canon CP-200 - CUPS+Gutenprint v5.2.10
Canon	Canon CP-220 - CUPS+Gutenprint v5.2.10
Canon	Canon CP-300 - CUPS+Gutenprint v5.2.10
Canon	Canon CP-330 - CUPS+Gutenprint v5.2.10
Canon	Canon E500 series - CUPS+Gutenprint v5.2.10
Canon	Canon E510 series - CUPS+Gutenprint v5.2.10
Canon	Canon E600 series - CUPS+Gutenprint v5.2.10
Canon	Canon E610 series - CUPS+Gutenprint v5.2.10
Canon	Canon GP 335 - CUPS+Gutenprint v5.2.10
Canon	Canon i70 - CUPS+Gutenprint v5.2.10
Canon	Canon i80 - CUPS+Gutenprint v5.2.10
Canon	Canon i450 - CUPS+Gutenprint v5.2.10
Canon	Canon i450X - CUPS+Gutenprint v5.2.10
Canon	Canon i455 - CUPS+Gutenprint v5.2.10
Canon	Canon i455X - CUPS+Gutenprint v5.2.10
Canon	Canon i470D - CUPS+Gutenprint v5.2.10
Canon	Canon i475D - CUPS+Gutenprint v5.2.10

Producer	Model
Canon	Canon i550 - CUPS+Gutenprint v5.2.10
Canon	Canon i550X - CUPS+Gutenprint v5.2.10
Canon	Canon i560 - CUPS+Gutenprint v5.2.10
Canon	Canon i560X - CUPS+Gutenprint v5.2.10
Canon	Canon i850 - CUPS+Gutenprint v5.2.10
Canon	Canon i850old - CUPS+Gutenprint v5.2.10
Canon	Canon i860 - CUPS+Gutenprint v5.2.10
Canon	Canon i860old - CUPS+Gutenprint v5.2.10
Canon	Canon i865 - CUPS+Gutenprint v5.2.10
Canon	Canon i865old - CUPS+Gutenprint v5.2.10
Canon	Canon i900D - CUPS+Gutenprint v5.2.10
Canon	Canon i905D - CUPS+Gutenprint v5.2.10
Canon	Canon i950 - CUPS+Gutenprint v5.2.10
Canon	Canon i960 - CUPS+Gutenprint v5.2.10
Canon	Canon i965 - CUPS+Gutenprint v5.2.10
Canon	Canon i990 - CUPS+Gutenprint v5.2.10
Canon	Canon i6100 - CUPS+Gutenprint v5.2.10
Canon	Canon i6500 - CUPS+Gutenprint v5.2.10
Canon	Canon i9100 - CUPS+Gutenprint v5.2.10
Canon	Canon i9900 - CUPS+Gutenprint v5.2.10
Canon	Canon i9950 - CUPS+Gutenprint v5.2.10
Canon	Canon imageRunner 330s - CUPS+Gutenprint v5.2.10
Canon	Canon iP2700 series - CUPS+Gutenprint v5.2.10
Canon	Canon iP3300 series - CUPS+Gutenprint v5.2.10
Canon	Canon iP3500 series - CUPS+Gutenprint v5.2.10
Canon	Canon iP3600 series - CUPS+Gutenprint v5.2.10
Canon	Canon iP4200 series - CUPS+Gutenprint v5.2.10
Canon	Canon iP4300 series - CUPS+Gutenprint v5.2.10
Canon	Canon iP4500 series - CUPS+Gutenprint v5.2.10
Canon	Canon iP4600 series - CUPS+Gutenprint v5.2.10
Canon	Canon iP4700 series - CUPS+Gutenprint v5.2.10
Canon	Canon iP4800 series - CUPS+Gutenprint v5.2.10
Canon	Canon iP4900 series - CUPS+Gutenprint v5.2.10
Canon	Canon iP5200R series - CUPS+Gutenprint v5.2.10
Canon	Canon iP6600D series - CUPS+Gutenprint v5.2.10
Canon	Canon iP6700D series - CUPS+Gutenprint v5.2.10
Canon	Canon iP7200 series - CUPS+Gutenprint v5.2.10
Canon	Canon iX5000 series - CUPS+Gutenprint v5.2.10
Canon	Canon iX6500 series - CUPS+Gutenprint v5.2.10
Canon	Canon iX7000 series - CUPS+Gutenprint v5.2.10
Canon	Canon LBP-4sx - CUPS+Gutenprint v5.2.10
Canon	Canon LBP-430 - CUPS+Gutenprint v5.2.10
Canon	Canon LBP-1000 - CUPS+Gutenprint v5.2.10
Canon	Canon LBP-1260 - CUPS+Gutenprint v5.2.10
Canon	Canon LBP-1760 - CUPS+Gutenprint v5.2.10
Canon	Canon LBP-3360 - CUPS+Gutenprint v5.2.10



Producer	Model
Canon	Canon MP520 series - CUPS+Gutenprint v5.2.10
Canon	Canon MP530 series - CUPS+Gutenprint v5.2.10
Canon	Canon MP540 series - CUPS+Gutenprint v5.2.10
Canon	Canon MP550 series - CUPS+Gutenprint v5.2.10
Canon	Canon MP560 series - CUPS+Gutenprint v5.2.10
Canon	Canon MP600 series - CUPS+Gutenprint v5.2.10
Canon	Canon MP610 series - CUPS+Gutenprint v5.2.10
Canon	Canon MP620 series - CUPS+Gutenprint v5.2.10
Canon	Canon MP630 series - CUPS+Gutenprint v5.2.10
Canon	Canon MP640 series - CUPS+Gutenprint v5.2.10
Canon	Canon MP700 series - CUPS+Gutenprint v5.2.10
Canon	Canon MP710 series - CUPS+Gutenprint v5.2.10
Canon	Canon MP730 series - CUPS+Gutenprint v5.2.10
Canon	Canon MP740 series - CUPS+Gutenprint v5.2.10
Canon	Canon MP750 series - CUPS+Gutenprint v5.2.10
Canon	Canon MP760 series - CUPS+Gutenprint v5.2.10
Canon	Canon MP770 series - CUPS+Gutenprint v5.2.10
Canon	Canon MP780 series - CUPS+Gutenprint v5.2.10
Canon	Canon MP790 series - CUPS+Gutenprint v5.2.10
Canon	Canon MP800 series - CUPS+Gutenprint v5.2.10
Canon	Canon MP810 series - CUPS+Gutenprint v5.2.10
Canon	Canon MP830 series - CUPS+Gutenprint v5.2.10
Canon	Canon MP900 series - CUPS+Gutenprint v5.2.10
Canon	Canon MP950 series - CUPS+Gutenprint v5.2.10
Canon	Canon MP960 series - CUPS+Gutenprint v5.2.10
Canon	Canon MP970 series - CUPS+Gutenprint v5.2.10
Canon	Canon MP980 series - CUPS+Gutenprint v5.2.10
Canon	Canon MP990 series - CUPS+Gutenprint v5.2.10
Canon	Canon MultiPASS MP360 - CUPS+Gutenprint v5.2.10
Canon	Canon MultiPASS MP370 - CUPS+Gutenprint v5.2.10
Canon	Canon MultiPASS MP390 - CUPS+Gutenprint v5.2.10
Canon	Canon MultiPASS MP700 - CUPS+Gutenprint v5.2.10
Canon	Canon MultiPASS MP730 - CUPS+Gutenprint v5.2.10
Canon	Canon MX300 series - CUPS+Gutenprint v5.2.10
Canon	Canon MX310 series - CUPS+Gutenprint v5.2.10
Canon	Canon MX320 series - CUPS+Gutenprint v5.2.10
Canon	Canon MX330 series - CUPS+Gutenprint v5.2.10
Canon	Canon MX340 series - CUPS+Gutenprint v5.2.10
Canon	Canon MX350 series - CUPS+Gutenprint v5.2.10
Canon	Canon MX360 series - CUPS+Gutenprint v5.2.10
Canon	Canon MX370 series - CUPS+Gutenprint v5.2.10
Canon	Canon MX390 series - CUPS+Gutenprint v5.2.10
Canon	Canon MX410 series - CUPS+Gutenprint v5.2.10
Canon	Canon MX420 series - CUPS+Gutenprint v5.2.10
Canon	Canon MX430 series - CUPS+Gutenprint v5.2.10
Canon	Canon MX450 series - CUPS+Gutenprint v5.2.10

Producer	Model
Canon	Canon MX510 series - CUPS+Gutenprint v5.2.10
Canon	Canon MX520 series - CUPS+Gutenprint v5.2.10
Canon	Canon MX700 series - CUPS+Gutenprint v5.2.10
Canon	Canon MX710 series - CUPS+Gutenprint v5.2.10
Canon	Canon MX720 series - CUPS+Gutenprint v5.2.10
Canon	Canon MX850 series - CUPS+Gutenprint v5.2.10
Canon	Canon MX860 series - CUPS+Gutenprint v5.2.10
Canon	Canon MX870 series - CUPS+Gutenprint v5.2.10
Canon	Canon MX880 series - CUPS+Gutenprint v5.2.10
Canon	Canon MX890 series - CUPS+Gutenprint v5.2.10
Canon	Canon MX920 series - CUPS+Gutenprint v5.2.10
Canon	Canon MX7600 series - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA E500 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA E510 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA E518 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA E600 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA E608 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA E610 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA E618 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP90 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP90v - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP100 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP2000 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP2700 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP2701 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP2702 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP2740 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP2760 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP2770 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP2772 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP2780 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP2788 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP3000 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP3100 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP3300 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP3500 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP3600 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP3680 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP4000 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP4000R - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP4100 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP4100R - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP4200 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP4300 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP4500 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP4600 - CUPS+Gutenprint v5.2.10

Producer	Model
Canon	Canon PIXMA iP4680 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP4700 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP4760 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP4800 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP4810 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP4820 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP4840 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP4850 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP4870 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP4880 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP4900 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP4910 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP4920 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP4940 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP4950 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP4970 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP4980 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP5000 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP5200 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP5200R - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP5300 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP6000D - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP6100D - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP6210D - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP6220D - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP6310D - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP6320D - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP6600D - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP6700D - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP7100 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP7210 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP7220 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP7240 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP7250 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP7260 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP7270 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP7280 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP7500 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP8100 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP8500 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP8600 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iP9910 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iX4000 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iX5000 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iX6500 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA iX6510 - CUPS+Gutenprint v5.2.10









Producer	Model
Canon	Canon PIXMA MG7150 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MG7170 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MG7180 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MG8100 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MG8120 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MG8140 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MG8150 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MG8170 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MG8180 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MG8200 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MG8220 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MG8240 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MG8250 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MG8270 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MG8280 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA mini220 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA mini320 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA mini360 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP140 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP145 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP150 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP160 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP170 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP180 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP190 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP198 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP210 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP218 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP220 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP228 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP230 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP236 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP237 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP240 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP245 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP250 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP252 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP258 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP259 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP260 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP268 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP270 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP272 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP276 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP280 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP282 - CUPS+Gutenprint v5.2.10

Producer	Model
Canon	Canon PIXMA MP287 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP288 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP360 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP370 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP375R - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP390 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP450 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP460 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP470 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP476 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP480 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP486 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP490 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP492 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP493 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP495 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP496 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP497 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP498 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP499 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP500 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP510 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP520 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP530 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP540 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP545 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP550 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP558 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP560 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP568 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP600 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP600R - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP610 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP620 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP628 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP630 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP638 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP640 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP648 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP700 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP710 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP730 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP740 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP750 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP760 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP770 - CUPS+Gutenprint v5.2.10

Producer	Model
Canon	Canon PIXMA MP780 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP790 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP800 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP800R - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP810 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP830 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP900 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP950 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP960 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP970 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP980 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP988 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP990 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MP996 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX300 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX308 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX310 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX318 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX320 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX328 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX330 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX338 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX340 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX347 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX348 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX350 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX357 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX358 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX360 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX366 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX368 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX370 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX371 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX372 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX374 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX375 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX376 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX377 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX378 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX391 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX392 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX394 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX395 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX396 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX397 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX398 - CUPS+Gutenprint v5.2.10



Producer	Model
Canon	Canon PIXMA MX725 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX726 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX727 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX728 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX850 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX860 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX868 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX870 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX876 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX880 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX882 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX884 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX885 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX886 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX888 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX890 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX892 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX894 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX895 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX897 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX898 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX922 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX924 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX925 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX926 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX927 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX928 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA MX7600 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA Pro9000 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA Pro9000mk2 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA Pro9500 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXMA Pro9500mk2 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS iP2700 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS iP3100 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS iP3300 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS iP3500 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS iP3600 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS iP4100 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS iP4100R - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS iP4200 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS iP4300 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS iP4500 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS iP4600 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS iP4700 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS iP4830 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS iP4930 - CUPS+Gutenprint v5.2.10



Producer	Model
Canon	Canon PIXUS iP5200R - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS iP6100D - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS iP6600D - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS iP6700D - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS iP7100 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS iP7230 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS iP7500 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS iP8100 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS iP8600 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS iP9910 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS iX5000 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS iX6530 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS iX7000 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MG2130 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MG3130 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MG3230 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MG3530 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MG4130 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MG4230 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MG5130 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MG5230 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MG5330 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MG5430 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MG5530 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MG6130 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MG6230 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MG6330 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MG6530 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MG7130 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MG8130 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MG8230 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP170 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP270 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP280 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP360 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP370 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP375R - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP390 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP450 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP460 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP470 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP480 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP490 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP493 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP500 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP510 - CUPS+Gutenprint v5.2.10

Producer	Model
Canon	Canon PIXUS MP520 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP540 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP550 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP560 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP600 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP610 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP620 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP630 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP640 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP700 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP710 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP730 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP740 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP770 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP790 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP800 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP810 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP830 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP900 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP950 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP960 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP970 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP980 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MP990 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MX350 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MX420 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MX513 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MX523 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MX850 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MX860 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MX870 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MX883 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MX893 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MX923 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS MX7600 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS Pro9000 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS Pro9000mk2 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS Pro9500 - CUPS+Gutenprint v5.2.10
Canon	Canon PIXUS Pro9500mk2 - CUPS+Gutenprint v5.2.10
Canon	Canon Pro9000 Mk.II series - CUPS+Gutenprint v5.2.10
Canon	Canon Pro9000 series - CUPS+Gutenprint v5.2.10
Canon	Canon Pro9500 Mk.II series - CUPS+Gutenprint v5.2.10
Canon	Canon Pro9500 series - CUPS+Gutenprint v5.2.10
Canon	Canon S100 - CUPS+Gutenprint v5.2.10
Canon	Canon S200 - CUPS+Gutenprint v5.2.10
Canon	Canon S300 - CUPS+Gutenprint v5.2.10

Producer	Model
Canon	Canon S330 - CUPS+Gutenprint v5.2.10
Canon	Canon S400 - CUPS+Gutenprint v5.2.10
Canon	Canon S450 - CUPS+Gutenprint v5.2.10
Canon	Canon S500 - CUPS+Gutenprint v5.2.10
Canon	Canon S520 - CUPS+Gutenprint v5.2.10
Canon	Canon S530D - CUPS+Gutenprint v5.2.10
Canon	Canon S600 - CUPS+Gutenprint v5.2.10
Canon	Canon S630 - CUPS+Gutenprint v5.2.10
Canon	Canon S750 - CUPS+Gutenprint v5.2.10
Canon	Canon S800 - CUPS+Gutenprint v5.2.10
Canon	Canon S820 - CUPS+Gutenprint v5.2.10
Canon	Canon S830D - CUPS+Gutenprint v5.2.10
Canon	Canon S900 - CUPS+Gutenprint v5.2.10
Canon	Canon S4500 - CUPS+Gutenprint v5.2.10
Canon	Canon S9000 - CUPS+Gutenprint v5.2.10
Canon	Canon SELPHY CP400 - CUPS+Gutenprint v5.2.10
Canon	Canon SELPHY CP500 - CUPS+Gutenprint v5.2.10
Canon	Canon SELPHY CP510 - CUPS+Gutenprint v5.2.10
Canon	Canon SELPHY CP520 - CUPS+Gutenprint v5.2.10
Canon	Canon SELPHY CP530 - CUPS+Gutenprint v5.2.10
Canon	Canon SELPHY CP600 - CUPS+Gutenprint v5.2.10
Canon	Canon SELPHY CP710 - CUPS+Gutenprint v5.2.10
Canon	Canon SELPHY CP720 - CUPS+Gutenprint v5.2.10
Canon	Canon SELPHY CP730 - CUPS+Gutenprint v5.2.10
Canon	Canon SELPHY CP740 - CUPS+Gutenprint v5.2.10
Canon	Canon SELPHY CP750 - CUPS+Gutenprint v5.2.10
Canon	Canon SELPHY CP760 - CUPS+Gutenprint v5.2.10
Canon	Canon SELPHY CP770 - CUPS+Gutenprint v5.2.10
Canon	Canon SELPHY CP780 - CUPS+Gutenprint v5.2.10
Canon	Canon SELPHY CP790 - CUPS+Gutenprint v5.2.10
Canon	Canon SELPHY CP800 - CUPS+Gutenprint v5.2.10
Canon	Canon SELPHY CP810 - CUPS+Gutenprint v5.2.10
Canon	Canon SELPHY CP900 - CUPS+Gutenprint v5.2.10
Canon	Canon SELPHY DS700 - CUPS+Gutenprint v5.2.10
Canon	Canon SELPHY DS810 - CUPS+Gutenprint v5.2.10
Canon	Canon SELPHY ES1 - CUPS+Gutenprint v5.2.10
Canon	Canon SELPHY ES2 - CUPS+Gutenprint v5.2.10
Canon	Canon SELPHY ES3 - CUPS+Gutenprint v5.2.10
Canon	Canon SELPHY ES20 - CUPS+Gutenprint v5.2.10
Canon	Canon SELPHY ES30 - CUPS+Gutenprint v5.2.10
Canon	Canon SELPHY ES40 - CUPS+Gutenprint v5.2.10
Canon	Canon SmartBase MP360 - CUPS+Gutenprint v5.2.10
Canon	Canon SmartBase MP360S - CUPS+Gutenprint v5.2.10
Canon	Canon SmartBase MP370 - CUPS+Gutenprint v5.2.10
Canon	Canon SmartBase MP390 - CUPS+Gutenprint v5.2.10
Canon	Canon SmartBase MP700 - CUPS+Gutenprint v5.2.10

Producer	Model
Canon	Canon SmartBase MP730 - CUPS+Gutenprint v5.2.10
Citizen	Citizen CW-01 - CUPS+Gutenprint v5.2.10
Citizen	Citizen CW-02 - CUPS+Gutenprint v5.2.10
Citizen	Citizen CX - CUPS+Gutenprint v5.2.10
Citizen	Citizen CX-W - CUPS+Gutenprint v5.2.10
Citizen	Citizen CY - CUPS+Gutenprint v5.2.10
Citizen	Citizen OP900 - CUPS+Gutenprint v5.2.10
Citizen	Citizen OP900II - CUPS+Gutenprint v5.2.10
Citizen	Citizen ProJet II - CUPS+Gutenprint v5.2.10
Compaq	Compaq IJ1200 - CUPS+Gutenprint v5.2.10
DEC	DEC 1800 - CUPS+Gutenprint v5.2.10
DEC	DEC LN17 - CUPS+Gutenprint v5.2.10
DNP	Dai Nippon Printing DS40 - CUPS+Gutenprint v5.2.10
DNP	Dai Nippon Printing DS80 - CUPS+Gutenprint v5.2.10
DNP	Dai Nippon Printing DSRX1 - CUPS+Gutenprint v5.2.10
Dymo	Dymo Label Printer
Epson	Epson 9-Pin Series
Epson	Epson 24-Pin Series
Epson	Epson ActionLaser 1100 - CUPS+Gutenprint v5.2.10
Epson	Epson ActionLaser II - CUPS+Gutenprint v5.2.10
Epson	Epson AL-C2000 - CUPS+Gutenprint v5.2.10
Epson	Epson AL-C2000 PS3 - CUPS+Gutenprint v5.2.10
Epson	Epson AL-C8500 - CUPS+Gutenprint v5.2.10
Epson	Epson AL-C8500PS - CUPS+Gutenprint v5.2.10
Epson	Epson AL-C8600 - CUPS+Gutenprint v5.2.10
Epson	Epson AL-C8600 PS3 - CUPS+Gutenprint v5.2.10
Epson	Epson Artisan 50 - CUPS+Gutenprint v5.2.10
Epson	Epson Artisan 700 - CUPS+Gutenprint v5.2.10
Epson	Epson Artisan 710 - CUPS+Gutenprint v5.2.10
Epson	Epson Artisan 800 - CUPS+Gutenprint v5.2.10
Epson	Epson Artisan 810 - CUPS+Gutenprint v5.2.10
Epson	Epson Artisan 835 - CUPS+Gutenprint v5.2.10
Epson	Epson B-300 - CUPS+Gutenprint v5.2.10
Epson	Epson B-308 - CUPS+Gutenprint v5.2.10
Epson	Epson B-310 - CUPS+Gutenprint v5.2.10
Epson	Epson B-310N - CUPS+Gutenprint v5.2.10
Epson	Epson B-500DN - CUPS+Gutenprint v5.2.10
Epson	Epson B-508DN - CUPS+Gutenprint v5.2.10
Epson	Epson B-510DN - CUPS+Gutenprint v5.2.10
Epson	Epson CL 700 - CUPS+Gutenprint v5.2.10
Epson	Epson CL 750 - CUPS+Gutenprint v5.2.10
Epson	Epson CL 760 - CUPS+Gutenprint v5.2.10
Epson	Epson E 100 - CUPS+Gutenprint v5.2.10
Epson	Epson E 150 - CUPS+Gutenprint v5.2.10
Epson	Epson E 200 - CUPS+Gutenprint v5.2.10
Epson	Epson E 300 - CUPS+Gutenprint v5.2.10

Producer	Model
Epson	Epson E 500 - CUPS+Gutenprint v5.2.10
Epson	Epson E 520 - CUPS+Gutenprint v5.2.10
Epson	Epson E 700 - CUPS+Gutenprint v5.2.10
Epson	Epson E 720 - CUPS+Gutenprint v5.2.10
Epson	Epson EM 900C - CUPS+Gutenprint v5.2.10
Epson	Epson EM 930C - CUPS+Gutenprint v5.2.10
Epson	Epson EP 302 - CUPS+Gutenprint v5.2.10
Epson	Epson EP 702A - CUPS+Gutenprint v5.2.10
Epson	Epson EP 801A - CUPS+Gutenprint v5.2.10
Epson	Epson EP 901A - CUPS+Gutenprint v5.2.10
Epson	Epson EP 901F - CUPS+Gutenprint v5.2.10
Epson	Epson EPL-5200 - CUPS+Gutenprint v5.2.10
Epson	Epson EPL-5200+ - CUPS+Gutenprint v5.2.10
Epson	Epson EPL-5700 - CUPS+Gutenprint v5.2.10
Epson	Epson EPL-5700PS - CUPS+Gutenprint v5.2.10
Epson	Epson EPL-5800 - CUPS+Gutenprint v5.2.10
Epson	Epson EPL-5800PS - CUPS+Gutenprint v5.2.10
Epson	Epson EPL-5900 - CUPS+Gutenprint v5.2.10
Epson	Epson EPL-5900 PS3 - CUPS+Gutenprint v5.2.10
Epson	Epson EPL-6100 - CUPS+Gutenprint v5.2.10
Epson	Epson EPL-6100 PS3 - CUPS+Gutenprint v5.2.10
Epson	Epson EPL-7100 - CUPS+Gutenprint v5.2.10
Epson	Epson EPL-N2050 - CUPS+Gutenprint v5.2.10
Epson	Epson EPL-N2050+ - CUPS+Gutenprint v5.2.10
Epson	Epson EPL-N2050PS - CUPS+Gutenprint v5.2.10
Epson	Epson EPL-N2050PS+ - CUPS+Gutenprint v5.2.10
Epson	Epson EPL-N2120 - CUPS+Gutenprint v5.2.10
Epson	Epson EPL-N2500 - CUPS+Gutenprint v5.2.10
Epson	Epson EPL-N2500 PS3 - CUPS+Gutenprint v5.2.10
Epson	Epson EPL-N2750 - CUPS+Gutenprint v5.2.10
Epson	Epson EPL-N2750PS - CUPS+Gutenprint v5.2.10
Epson	Epson MC 2000 - CUPS+Gutenprint v5.2.10
Epson	Epson MC 5000 - CUPS+Gutenprint v5.2.10
Epson	Epson MC 7000 - CUPS+Gutenprint v5.2.10
Epson	Epson MC 9000 - CUPS+Gutenprint v5.2.10
Epson	Epson MC 10000 - CUPS+Gutenprint v5.2.10
Epson	Epson ME 300 - CUPS+Gutenprint v5.2.10
Epson	Epson ME 320 - CUPS+Gutenprint v5.2.10
Epson	Epson ME Office 70 - CUPS+Gutenprint v5.2.10
Epson	Epson ME Office 80W - CUPS+Gutenprint v5.2.10
Epson	Epson ME Office 360 - CUPS+Gutenprint v5.2.10
Epson	Epson ME Office 600F - CUPS+Gutenprint v5.2.10
Epson	Epson ME Office 620F - CUPS+Gutenprint v5.2.10
Epson	Epson ME Office 700FW - CUPS+Gutenprint v5.2.10
Epson	Epson ME Office 940FW - CUPS+Gutenprint v5.2.10
Epson	Epson ME Office 1100 - CUPS+Gutenprint v5.2.10

Producer	Model
Epson	Epson MJ 930C - CUPS+Gutenprint v5.2.10
Epson	Epson MJ 5100C - CUPS+Gutenprint v5.2.10
Epson	Epson MJ 6000C - CUPS+Gutenprint v5.2.10
Epson	Epson MJ 8000C - CUPS+Gutenprint v5.2.10
Epson	Epson New Stylus Color Series
Epson	Epson New Stylus Photo Series
Epson	Epson Offirio PX B300 - CUPS+Gutenprint v5.2.10
Epson	Epson Offirio PX B500 - CUPS+Gutenprint v5.2.10
Epson	Epson PictureMate - CUPS+Gutenprint v5.2.10
Epson	Epson PictureMate 100 - CUPS+Gutenprint v5.2.10
Epson	Epson PictureMate 200 - CUPS+Gutenprint v5.2.10
Epson	Epson PictureMate 210 - CUPS+Gutenprint v5.2.10
Epson	Epson PictureMate 215 - CUPS+Gutenprint v5.2.10
Epson	Epson PictureMate 240 - CUPS+Gutenprint v5.2.10
Epson	Epson PictureMate 250 - CUPS+Gutenprint v5.2.10
Epson	Epson PictureMate 260 - CUPS+Gutenprint v5.2.10
Epson	Epson PictureMate 270 - CUPS+Gutenprint v5.2.10
Epson	Epson PictureMate 280 - CUPS+Gutenprint v5.2.10
Epson	Epson PictureMate 290 - CUPS+Gutenprint v5.2.10
Epson	Epson PictureMate 500 - CUPS+Gutenprint v5.2.10
Epson	Epson PictureMate 2005 - CUPS+Gutenprint v5.2.10
Epson	Epson PictureMate Dash - CUPS+Gutenprint v5.2.10
Epson	Epson PictureMate Deluxe - CUPS+Gutenprint v5.2.10
Epson	Epson PictureMate Flash - CUPS+Gutenprint v5.2.10
Epson	Epson PictureMate Pal - CUPS+Gutenprint v5.2.10
Epson	Epson PictureMate Snap - CUPS+Gutenprint v5.2.10
Epson	Epson PM 670C - CUPS+Gutenprint v5.2.10
Epson	Epson PM 700C - CUPS+Gutenprint v5.2.10
Epson	Epson PM 730C - CUPS+Gutenprint v5.2.10
Epson	Epson PM 740C - CUPS+Gutenprint v5.2.10
Epson	Epson PM 750C - CUPS+Gutenprint v5.2.10
Epson	Epson PM 760C - CUPS+Gutenprint v5.2.10
Epson	Epson PM 770C - CUPS+Gutenprint v5.2.10
Epson	Epson PM 780C - CUPS+Gutenprint v5.2.10
Epson	Epson PM 790PT - CUPS+Gutenprint v5.2.10
Epson	Epson PM 800C - CUPS+Gutenprint v5.2.10
Epson	Epson PM 850PT - CUPS+Gutenprint v5.2.10
Epson	Epson PM 870C - CUPS+Gutenprint v5.2.10
Epson	Epson PM 880C - CUPS+Gutenprint v5.2.10
Epson	Epson PM 930C - CUPS+Gutenprint v5.2.10
Epson	Epson PM 940C - CUPS+Gutenprint v5.2.10
Epson	Epson PM 950C - CUPS+Gutenprint v5.2.10
Epson	Epson PM 970C - CUPS+Gutenprint v5.2.10
Epson	Epson PM 980C - CUPS+Gutenprint v5.2.10
Epson	Epson PM 2000C - CUPS+Gutenprint v5.2.10
Epson	Epson PM 2200C - CUPS+Gutenprint v5.2.10

Producer	Model
Epson	Epson PM 3000C - CUPS+Gutenprint v5.2.10
Epson	Epson PM 3300C - CUPS+Gutenprint v5.2.10
Epson	Epson PM 3500C - CUPS+Gutenprint v5.2.10
Epson	Epson PM 3700C - CUPS+Gutenprint v5.2.10
Epson	Epson PM 4000PX - CUPS+Gutenprint v5.2.10
Epson	Epson PM 5000C - CUPS+Gutenprint v5.2.10
Epson	Epson PM 7000C - CUPS+Gutenprint v5.2.10
Epson	Epson PM 9000C - CUPS+Gutenprint v5.2.10
Epson	Epson PM 10000 - CUPS+Gutenprint v5.2.10
Epson	Epson PM A650 - CUPS+Gutenprint v5.2.10
Epson	Epson PM A750 - CUPS+Gutenprint v5.2.10
Epson	Epson PM A820 - CUPS+Gutenprint v5.2.10
Epson	Epson PM A890 - CUPS+Gutenprint v5.2.10
Epson	Epson PM A900 - CUPS+Gutenprint v5.2.10
Epson	Epson PM A940 - CUPS+Gutenprint v5.2.10
Epson	Epson PM A950 - CUPS+Gutenprint v5.2.10
Epson	Epson PM D600 - CUPS+Gutenprint v5.2.10
Epson	Epson PM D750 - CUPS+Gutenprint v5.2.10
Epson	Epson PM D770 - CUPS+Gutenprint v5.2.10
Epson	Epson PM D800 - CUPS+Gutenprint v5.2.10
Epson	Epson PM D870 - CUPS+Gutenprint v5.2.10
Epson	Epson PM D1000 - CUPS+Gutenprint v5.2.10
Epson	Epson PM G700 - CUPS+Gutenprint v5.2.10
Epson	Epson PM G720 - CUPS+Gutenprint v5.2.10
Epson	Epson PM G730 - CUPS+Gutenprint v5.2.10
Epson	Epson PM G800 - CUPS+Gutenprint v5.2.10
Epson	Epson PM G820 - CUPS+Gutenprint v5.2.10
Epson	Epson PM G850 - CUPS+Gutenprint v5.2.10
Epson	Epson PM G4500 - CUPS+Gutenprint v5.2.10
Epson	Epson PM T960 - CUPS+Gutenprint v5.2.10
Epson	Epson PX 7V - CUPS+Gutenprint v5.2.10
Epson	Epson PX 101 - CUPS+Gutenprint v5.2.10
Epson	Epson PX 201 - CUPS+Gutenprint v5.2.10
Epson	Epson PX 204 - CUPS+Gutenprint v5.2.10
Epson	Epson PX 401A - CUPS+Gutenprint v5.2.10
Epson	Epson PX 504A - CUPS+Gutenprint v5.2.10
Epson	Epson PX 601F - CUPS+Gutenprint v5.2.10
Epson	Epson PX 1001 - CUPS+Gutenprint v5.2.10
Epson	Epson PX 1200 - CUPS+Gutenprint v5.2.10
Epson	Epson PX 1600F - CUPS+Gutenprint v5.2.10
Epson	Epson PX 1700F - CUPS+Gutenprint v5.2.10
Epson	Epson PX 5500 - CUPS+Gutenprint v5.2.10
Epson	Epson PX 7000 - CUPS+Gutenprint v5.2.10
Epson	Epson PX 9000 - CUPS+Gutenprint v5.2.10
Epson	Epson PX A650 - CUPS+Gutenprint v5.2.10
Epson	Epson PX G900 - CUPS+Gutenprint v5.2.10

Producer	Model
Epson	Epson PX G920 - CUPS+Gutenprint v5.2.10
Epson	Epson PX G5000 - CUPS+Gutenprint v5.2.10
Epson	Epson PX G5300 - CUPS+Gutenprint v5.2.10
Epson	Epson PX G5600 - CUPS+Gutenprint v5.2.10
Epson	Epson PX V500 - CUPS+Gutenprint v5.2.10
Epson	Epson PX V600 - CUPS+Gutenprint v5.2.10
Epson	Epson PX V630 - CUPS+Gutenprint v5.2.10
Epson	Epson PX V780 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C20 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C20SX - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C20UX - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C40 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C40SX - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C40UX - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C41 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C41SX - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C41UX - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C42 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C42SX - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C42UX - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C43 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C43SX - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C43UX - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C44 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C44SX - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C44UX - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C45 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C46 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C48 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C50 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C60 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C61 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C62 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C63 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C64 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C65 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C66 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C68 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C70 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C79 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C80 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C82 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C83 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C84 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C85 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C86 - CUPS+Gutenprint v5.2.10



Producer	Model
Epson	Epson Stylus C87 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C88 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C92 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C110 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus C120 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Color - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Color 8 3 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Color 400 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Color 440 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Color 460 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Color 480 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Color 500 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Color 580 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Color 600 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Color 640 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Color 660 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Color 670 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Color 680 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Color 740 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Color 760 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Color 777 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Color 800 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Color 850 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Color 860 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Color 880 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Color 900 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Color 980 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Color 1160 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Color 1500 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Color 1520 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Color 3000 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Color I - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Color II - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Color IIs - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Color PRO - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Color Series
Epson	Epson Stylus CX1500 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX3100 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX3200 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX3500 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX3600 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX3650 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX3700 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX3800 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX3805 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX3810 - CUPS+Gutenprint v5.2.10

Producer	Model
Epson	Epson Stylus CX3900 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX4100 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX4200 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX4400 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX4500 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX4600 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX4700 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX4800 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX4900 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX5000 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX5000F - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX5100 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX5200 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX5300 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX5400 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX5500 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX5600 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX5700 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX5800 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX6000 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX6300 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX6400 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX6500 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX6600 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX7000F - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX7300 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX7400 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX7700 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX7800 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX8300 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX8400 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX9300F - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX9400 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX9400F - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus CX9475F - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus D68 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus D78 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus D88 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus D92 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus D120 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus DX3800 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus DX3850 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus DX4000 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus DX4050 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus DX4200 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus DX4250 - CUPS+Gutenprint v5.2.10

Producer	Model
Epson	Epson Stylus DX4400 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus DX4450 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus DX4800 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus DX4850 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus DX7000F - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus DX7400 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus DX7450 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus DX8400 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus DX8450 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus DX9400F - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus NX100 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus NX105 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus NX115 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus NX200 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus NX215 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus NX300 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus NX400 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus NX415 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus NX420 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus NX515 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus NX530 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus NX630 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus NX635 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus NX645 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Office B30 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Office B33 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Office B40W - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Office B1100 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Office BX300F - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Office BX535WD - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Office BX600FW - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Office BX630FW - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Office BX635FWD - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Office SX600FW - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Office T30 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Office T33 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Office T40W - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Office T1100 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Office T1110 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Office TX300F - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Office TX600FW - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Office TX620FWD - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo 700 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo 720 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo 750 - CUPS+Gutenprint v5.2.10

Producer	Model
Epson	Epson Stylus Photo 780 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo 785 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo 790 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo 810 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo 820 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo 825 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo 830 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo 830U - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo 870 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo 875 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo 890 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo 895 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo 900 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo 915 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo 925 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo 935 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo 950 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo 960 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo 1200 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo 1270 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo 1280 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo 1290 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo 1290s - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo 1400 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo 1410 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo 2000P - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo 2100 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo 2200 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo EX - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo EX3 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo P50 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo PX650 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo PX700W - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo PX710W - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo PX800FW - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo PX810FW - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo R200 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo R210 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo R220 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo R230 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo R240 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo R245 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo R260 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo R265 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo R270 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo R280 - CUPS+Gutenprint v5.2.10

Producer	Model
Epson	Epson Stylus Photo R285 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo R290 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo R300 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo R310 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo R320 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo R340 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo R350 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo R360 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo R380 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo R390 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo R800 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo R1800 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo R1900 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo R2000 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo R2400 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo R2880 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo R3000 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo RX400 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo RX420 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo RX425 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo RX430 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo RX500 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo RX510 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo RX560 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo RX580 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo RX585 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo RX590 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo RX595 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo RX600 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo RX610 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo RX620 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo RX630 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo RX640 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo RX650 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo RX680 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo RX685 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo RX690 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo RX700 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo Series
Epson	Epson Stylus Photo TX700W - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo TX710W - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo TX800FW - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Photo TX810FW - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Pro 3800 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Pro 3880 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Pro 3885 - CUPS+Gutenprint v5.2.10

Producer	Model
Epson	Epson Stylus Pro 4000 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Pro 4800 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Pro 4800/4880 Back Compatible - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Pro 4880 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Pro 5000 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Pro 5500 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Pro 7000 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Pro 7500 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Pro 7600 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Pro 7700 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Pro 7800 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Pro 7880 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Pro 7890 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Pro 7900 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Pro 9000 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Pro 9500 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Pro 9600 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Pro 9700 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Pro 9800 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Pro 9880 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Pro 9890 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Pro 9900 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Pro 10000 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Pro 11800 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Pro 11800/11880 Back Compatible - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Pro 11880 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Pro XL - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus S20 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus S21 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus S50 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Scan 2000 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus Scan 2500 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus SX100 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus SX105 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus SX110 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus SX115 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus SX200 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus SX205 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus SX210 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus SX215 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus SX400 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus SX405 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus SX410 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus SX415 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus SX420 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus SX445W - CUPS+Gutenprint v5.2.10

Producer	Model
Epson	Epson Stylus SX510W - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus SX515 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus SX525 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus SX535FW - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus SX600FW - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus SX610FW - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus SX615 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus SX630 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus SX635 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus SX645 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus SX650 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus T13 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus T20 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus T21 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus T22 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus T22E - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus T26 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus T30 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus T40W - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus T50 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus T59 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus T60 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus TX100 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus TX101 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus TX102 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus TX103 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus TX104 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus TX105 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus TX106 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus TX109 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus TX110 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus TX125 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus TX200 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus TX210 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus TX300F - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus TX400 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus TX410 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus TX420 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus TX510FN - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus TX550W - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus TX610FW - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus TX615 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus TX630 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus TX635 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus TX645 - CUPS+Gutenprint v5.2.10
Epson	Epson Stylus TX650 - CUPS+Gutenprint v5.2.10

Producer	Model
Epson	Epson Stylus TX659 - CUPS+Gutenprint v5.2.10
Epson	Epson WF-7010 Series - CUPS+Gutenprint v5.2.10
Epson	Epson WF-7011 Series - CUPS+Gutenprint v5.2.10
Epson	Epson WF-7015 Series - CUPS+Gutenprint v5.2.10
Epson	Epson WF-7018 Series - CUPS+Gutenprint v5.2.10
Epson	Epson WF-7510 Series - CUPS+Gutenprint v5.2.10
Epson	Epson WF-7511 Series - CUPS+Gutenprint v5.2.10
Epson	Epson WF-7515 Series - CUPS+Gutenprint v5.2.10
Epson	Epson WF-7520 Series - CUPS+Gutenprint v5.2.10
Epson	Epson WF-7521 Series - CUPS+Gutenprint v5.2.10
Epson	Epson WF-7525 Series - CUPS+Gutenprint v5.2.10
Epson	Epson WorkForce 30 - CUPS+Gutenprint v5.2.10
Epson	Epson WorkForce 40 - CUPS+Gutenprint v5.2.10
Epson	Epson WorkForce 310 - CUPS+Gutenprint v5.2.10
Epson	Epson WorkForce 315 - CUPS+Gutenprint v5.2.10
Epson	Epson WorkForce 500 - CUPS+Gutenprint v5.2.10
Epson	Epson WorkForce 545 - CUPS+Gutenprint v5.2.10
Epson	Epson WorkForce 600 - CUPS+Gutenprint v5.2.10
Epson	Epson WorkForce 610 - CUPS+Gutenprint v5.2.10
Epson	Epson WorkForce 615 - CUPS+Gutenprint v5.2.10
Epson	Epson WorkForce 630 - CUPS+Gutenprint v5.2.10
Epson	Epson WorkForce 635 - CUPS+Gutenprint v5.2.10
Epson	Epson WorkForce 645 - CUPS+Gutenprint v5.2.10
Epson	Epson WorkForce 1100 - CUPS+Gutenprint v5.2.10
Fujifilm	Fujifilm FinePix-NX-500 - CUPS+Gutenprint v5.2.10
Fujifilm	Fujifilm Printpix-CX-400 - CUPS+Gutenprint v5.2.10
Fujifilm	Fujifilm Printpix-CX-550 - CUPS+Gutenprint v5.2.10
Fujitsu	Fujitsu PrintPartner 10V - CUPS+Gutenprint v5.2.10
Fujitsu	Fujitsu PrintPartner 16DV - CUPS+Gutenprint v5.2.10
Fujitsu	Fujitsu PrintPartner 20W - CUPS+Gutenprint v5.2.10
Fujitsu	Fujitsu PrintPartner 8000 - CUPS+Gutenprint v5.2.10
Generic	Generic PCL 4 LF Printer - CUPS+Gutenprint v5.2.10
Generic	Generic PCL 4 Printer - CUPS+Gutenprint v5.2.10
Generic	Generic PCL 5 LF Printer - CUPS+Gutenprint v5.2.10
Generic	Generic PCL 5 Printer - CUPS+Gutenprint v5.2.10
Generic	Generic PCL 5c LF Printer - CUPS+Gutenprint v5.2.10
Generic	Generic PCL 5c Printer - CUPS+Gutenprint v5.2.10
Generic	Generic PCL 5e LF Printer - CUPS+Gutenprint v5.2.10
Generic	Generic PCL 5e Printer - CUPS+Gutenprint v5.2.10
Generic	Generic PCL 6/PCL XL LF Printer - CUPS+Gutenprint v5.2.10
Generic	Generic PCL 6/PCL XL Printer - CUPS+Gutenprint v5.2.10
Generic	Generic PCL Laser Printer
Generic	Generic PostScript Printer
Gestetner	Gestetner 2212 - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner 2712 - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner 3212 - CUPS+Gutenprint v5.2.10



Producer	Model
Gestetner	Gestetner 3502 - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner 3532/4235g - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner 4502 - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner 4532/4245g - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner 6002 - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner 7502 - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner 9002 - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner 10512 - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner DSm415 - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner DSm615 - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner DSm616 - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner DSm618 - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner DSm618d - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner DSm620 - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner DSm620d - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner DSm622 - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner DSm627 - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner DSm635/635G - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner DSm645/645G - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner DSm651 - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner DSm660 - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner DSm675 - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner DSm725 - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner DSm730 - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner DSm735/735G - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner DSm745/745G - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner MP 161/DSm416 - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner MP 2510/DSm725e - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner MP 2550 - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner MP 2550B - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner MP 3010/DSm730e - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner MP 3350 - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner MP 3350B - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner MP 4000 - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner MP 4000B - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner MP 5000 - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner MP 5000B - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner MP1100/DSm7110 - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner MP1350/DSm7135 - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner MP1600/DSm716 - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner MP2000/DSm721d - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner MP2500/DSm625 - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner MP3500/DSm735e - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner MP4500/DSm745e - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner MP5500/DSm755 - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner MP6500/DSm765 - CUPS+Gutenprint v5.2.10

Producer	Model
Gestetner	Gestetner MP7500/DSm775 - CUPS+Gutenprint v5.2.10
Gestetner	Gestetner MP9000/DSm790 - CUPS+Gutenprint v5.2.10
HP	HP Business Inkjet 2200 - CUPS+Gutenprint v5.2.10
HP	HP Business Inkjet 2230 - CUPS+Gutenprint v5.2.10
HP	HP Business Inkjet 2250 - CUPS+Gutenprint v5.2.10
HP	HP Business Inkjet 2250TN - CUPS+Gutenprint v5.2.10
HP	HP Business Inkjet 2280 - CUPS+Gutenprint v5.2.10
HP	HP Color Inkjet Printer CP1160 - CUPS+Gutenprint v5.2.10
HP	HP Color Inkjet Printer CP1700 - CUPS+Gutenprint v5.2.10
HP	HP Color LaserJet 5 - CUPS+Gutenprint v5.2.10
HP	HP Color LaserJet 2500 - CUPS+Gutenprint v5.2.10
HP	HP Color LaserJet 4500 - CUPS+Gutenprint v5.2.10
HP	HP Color LaserJet 4550 - CUPS+Gutenprint v5.2.10
HP	HP Color LaserJet 4600 - CUPS+Gutenprint v5.2.10
HP	HP Color LaserJet 5000 - CUPS+Gutenprint v5.2.10
HP	HP Color LaserJet 5500 - CUPS+Gutenprint v5.2.10
HP	HP Color LaserJet 8550GN - CUPS+Gutenprint v5.2.10
HP	HP Color LaserJet Series PCL 6 CUPS
HP	HP DesignJet 230 - CUPS+Gutenprint v5.2.10
HP	HP DesignJet 250C - CUPS+Gutenprint v5.2.10
HP	HP DesignJet 430 - CUPS+Gutenprint v5.2.10
HP	HP DesignJet 450C - CUPS+Gutenprint v5.2.10
HP	HP DesignJet 455CA - CUPS+Gutenprint v5.2.10
HP	HP DesignJet 488CA - CUPS+Gutenprint v5.2.10
HP	HP DesignJet 700 - CUPS+Gutenprint v5.2.10
HP	HP DesignJet 750C - CUPS+Gutenprint v5.2.10
HP	HP DesignJet 750C Plus - CUPS+Gutenprint v5.2.10
HP	HP DesignJet 2500CP - CUPS+Gutenprint v5.2.10
HP	HP DesignJet 3500CP - CUPS+Gutenprint v5.2.10
HP	HP DesignJet ColorPro CAD - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 340C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 400 - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 420C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 450 - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 500 - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 500C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 505J Plus - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 510 - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 520 - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 540C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 550C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 560C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 600 - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 600C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 610C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 610CL - CUPS+Gutenprint v5.2.10

Producer	Model
HP	HP DeskJet 612C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 640C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 648C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 660C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 670C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 670TV - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 672C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 680C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 682C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 690C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 692C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 693C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 694C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 695C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 697C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 810C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 812C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 815C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 816C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 825C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 830C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 832C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 840C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 841C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 842C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 843C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 845C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 850C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 855C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 870C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 880C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 882C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 890C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 895C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 916C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 920C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 930C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 932C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 933C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 934C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 935C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 940C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 948C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 950C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 952C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 955C - CUPS+Gutenprint v5.2.10

Producer	Model
HP	HP DeskJet 957C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 959C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 960C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 970C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 975C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 980C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 990C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 995C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 1100C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 1120C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 1125C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 1200C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 1220C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 1600C - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 1600CM - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 2000 - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 2500 - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 2500CM - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 3810 - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 3816 - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 3820 - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 3822 - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 5550 - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 5551 - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 6122 - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 6127 - CUPS+Gutenprint v5.2.10
HP	HP DeskJet 9300 - CUPS+Gutenprint v5.2.10
HP	HP DeskJet Series
HP	HP e-printer e20 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 2 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 2D - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 2P - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 2P Plus - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 3 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 3D - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 3P w/ PCL5 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 3P w/PS - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 4 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 4 Plus - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 4L - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 4M - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 4ML - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 4P - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 4Si - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 4V - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 5 - CUPS+Gutenprint v5.2.10

Producer	Model
HP	HP LaserJet 5L - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 5M - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 5MP - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 5P - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 5Si - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 6 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 6L - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 6MP - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 6P - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 1010 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 1012 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 1015 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 1022 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 1100 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 1100A - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 1150 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 1160 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 1200 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 1220 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 1300 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 1320 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 2100 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 2100M - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 2200 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 2300 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 2410 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 2420 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 2430 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 3015 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 3020 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 3030 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 3050 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 3052 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 3055 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 3200 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 3200m - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 3200se - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 3300 MFP - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 3310 MFP - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 3320 MFP - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 3320N MFP - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 3330 MFP - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 3380 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 3390 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 3392 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 4000 - CUPS+Gutenprint v5.2.10

Producer	Model
HP	HP LaserJet 4050 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 4100 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 4200 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 4240 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 4250 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 4300 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 4345 mfp - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 4350 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 5000 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 5100 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 5200 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 5200L - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 8000 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 8100 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 8150 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 9000 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 9040 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 9040 MFP - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 9050 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet 9050 MFP - CUPS+Gutenprint v5.2.10
HP	HP LaserJet M3027 MFP - CUPS+Gutenprint v5.2.10
HP	HP LaserJet M3035 MFP - CUPS+Gutenprint v5.2.10
HP	HP LaserJet M4345 MFP - CUPS+Gutenprint v5.2.10
HP	HP LaserJet M5025 MFP - CUPS+Gutenprint v5.2.10
HP	HP LaserJet M5035 MFP - CUPS+Gutenprint v5.2.10
HP	HP LaserJet P2010 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet P2015 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet P3004 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet P3005 - CUPS+Gutenprint v5.2.10
HP	HP LaserJet Series PCL 4/5
HP	HP LaserJet Series PCL 6 CUPS
HP	HP Mopier 240 - CUPS+Gutenprint v5.2.10
HP	HP Mopier 320 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet 300 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet 330 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet 350 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet 500 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet 520 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet 570 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet 580 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet 590 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet 600 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet 610 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet 625 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet 630 - CUPS+Gutenprint v5.2.10

Producer	Model
HP	HP OfficeJet 635 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet 700 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet 710 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet 720 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet 725 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet 5105 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet 5110 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet 5110xi - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet 6105 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet 6110 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet 7110 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet 7130 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet 7140 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet D125 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet D135 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet D145 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet D155 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet G55 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet G85 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet G95 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet K60 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet K60xi - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet K80 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet K80xi - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet LX - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet Pro 1150C - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet Pro 1170C - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet Pro 1175C - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet R40 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet R45 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet R60 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet R65 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet R80 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet T45 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet T65 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet V40 - CUPS+Gutenprint v5.2.10
HP	HP OfficeJet V40xi - CUPS+Gutenprint v5.2.10
HP	HP PhotoSmart 7150 - CUPS+Gutenprint v5.2.10
HP	HP PhotoSmart 7345 - CUPS+Gutenprint v5.2.10
HP	HP PhotoSmart 7350 - CUPS+Gutenprint v5.2.10
HP	HP PhotoSmart 7550 - CUPS+Gutenprint v5.2.10
HP	HP PhotoSmart P100 - CUPS+Gutenprint v5.2.10
HP	HP PhotoSmart P130 - CUPS+Gutenprint v5.2.10
HP	HP PhotoSmart P230 - CUPS+Gutenprint v5.2.10
HP	HP PhotoSmart P1000 - CUPS+Gutenprint v5.2.10
HP	HP PhotoSmart P1100 - CUPS+Gutenprint v5.2.10

Producer	Model
HP	HP PhotoSmart P1115 - CUPS+Gutenprint v5.2.10
HP	HP PhotoSmart P1215 - CUPS+Gutenprint v5.2.10
HP	HP PhotoSmart P1218 - CUPS+Gutenprint v5.2.10
HP	HP PhotoSmart P1315 - CUPS+Gutenprint v5.2.10
HP	HP PSC 370 - CUPS+Gutenprint v5.2.10
HP	HP PSC 380 - CUPS+Gutenprint v5.2.10
HP	HP PSC 500 - CUPS+Gutenprint v5.2.10
HP	HP PSC 750 - CUPS+Gutenprint v5.2.10
HP	HP PSC 950 - CUPS+Gutenprint v5.2.10
HP	HP PSC 950xi - CUPS+Gutenprint v5.2.10
HP	HP PSC 2110 - CUPS+Gutenprint v5.2.10
HP	HP PSC 2150 - CUPS+Gutenprint v5.2.10
HP	HP PSC 2210 - CUPS+Gutenprint v5.2.10
IBM	IBM 4019 - CUPS+Gutenprint v5.2.10
IBM	IBM 4029 030 LaserPrinter 10 - CUPS+Gutenprint v5.2.10
IBM	IBM 4312 - CUPS+Gutenprint v5.2.10
IBM	IBM Infoprint 12 - CUPS+Gutenprint v5.2.10
IBM	IBM Page Printer 3112 - CUPS+Gutenprint v5.2.10
Infotec	Infotec 4353 MF - CUPS+Gutenprint v5.2.10
Infotec	Infotec 4452 MF - CUPS+Gutenprint v5.2.10
Infotec	Infotec 4651 MF - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS 2015 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS 2018 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS 2018D - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS 2060 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS 2075 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS 2122 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS 2127 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS 2132 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS 2135 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS 2145 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS 2151 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS 2160 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS 2175 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS 2215 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS 2216 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS 2220 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS 2220D - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS 2225 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS 2230 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS 2235 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS 2245 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS 2255 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS 2265 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS 2275 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS 2316 - CUPS+Gutenprint v5.2.10



Producer	Model
Infotec	Infotec IS 2320 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS 2325 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS 2416 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS 2425 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS 2430 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS 2435 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS 2445 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS 3090 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS 3110 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS 3135 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS2022 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS2027 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS2032 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS2035 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS2045 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS2090 - CUPS+Gutenprint v5.2.10
Infotec	Infotec IS2105 - CUPS+Gutenprint v5.2.10
Infotec	Infotec MP 2550 - CUPS+Gutenprint v5.2.10
Infotec	Infotec MP 2550B - CUPS+Gutenprint v5.2.10
Infotec	Infotec MP 3350 - CUPS+Gutenprint v5.2.10
Infotec	Infotec MP 3350B - CUPS+Gutenprint v5.2.10
Infotec	Infotec MP 4000 - CUPS+Gutenprint v5.2.10
Infotec	Infotec MP 4000B - CUPS+Gutenprint v5.2.10
Infotec	Infotec MP 5000 - CUPS+Gutenprint v5.2.10
Infotec	Infotec MP 5000B - CUPS+Gutenprint v5.2.10
Intellitech	Intellitech IntelliBar Label Printer, 1.5
Kodak	Kodak 605 - CUPS+Gutenprint v5.2.10
Kodak	Kodak 805 - CUPS+Gutenprint v5.2.10
Kodak	Kodak 1400 - CUPS+Gutenprint v5.2.10
Kodak	Kodak 6800 - CUPS+Gutenprint v5.2.10
Kodak	Kodak 6850 - CUPS+Gutenprint v5.2.10
Kodak	Kodak 8500 - CUPS+Gutenprint v5.2.10
Kodak	Kodak 9810 - CUPS+Gutenprint v5.2.10
Kodak	Kodak EasyShare-G600-Printer-Dock - CUPS+Gutenprint v5.2.10
Kodak	Kodak Easyshare-Printer-Dock - CUPS+Gutenprint v5.2.10
Kodak	Kodak PD-4000 - CUPS+Gutenprint v5.2.10
Kodak	Kodak PD-6000 - CUPS+Gutenprint v5.2.10
Kodak	Kodak Photo-Printer - CUPS+Gutenprint v5.2.10
Kodak	Kodak Photo-Printer-500 - CUPS+Gutenprint v5.2.10
Kodak	Kodak Printer-Dock-Plus - CUPS+Gutenprint v5.2.10
Kodak	Kodak Printer-Dock-Plus-S3 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera CS-1815 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera F-1010 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-600 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-600 - KPD-L2 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-680 - CUPS+Gutenprint v5.2.10

Producer	Model
Kyocera	Kyocera FS-800 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-920 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-1000 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-1000+ - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-1010 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-1018MFP - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-1020D - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-1030D - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-1050 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-1118MFP - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-1200 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-1600 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-1600+ - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-1700 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-1700+ - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-1714M - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-1750 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-1800 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-1800+ - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-1900 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-1920 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-2000D - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-3500 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-3600 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-3600+ - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-3700 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-3700+ - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-3718M - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-3750 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-3800 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-3820N - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-3830N - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-3900DN - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-4000DN - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-5800C - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-5900C - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-6020 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-6026 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-6300 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-6500 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-6500+ - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-6700 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-6750 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-6900 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-6950DN - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-7000 - CUPS+Gutenprint v5.2.10

Producer	Model
Kyocera	Kyocera FS-7000+ - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-7028M - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-8000C - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-9000 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-9100DN - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-9130DN - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-9500DN - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera FS-9530DN - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera KM-1510 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera KM-1530 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera KM-1810 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera KM-1815 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera KM-1820 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera KM-2030 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera KM-2530 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera KM-3050 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera KM-3530 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera KM-4050 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera KM-4230 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera KM-4230/5230 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera KM-4530 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera KM-5050 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera KM-5230 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera KM-5530 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera KM-6030 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera KM-6230 - CUPS+Gutenprint v5.2.10
Kyocera	Kyocera KM-8030 - CUPS+Gutenprint v5.2.10
Lanier	Lanier 5622 - CUPS+Gutenprint v5.2.10
Lanier	Lanier 5627 - CUPS+Gutenprint v5.2.10
Lanier	Lanier 5632 - CUPS+Gutenprint v5.2.10
Lanier	Lanier 5635 - CUPS+Gutenprint v5.2.10
Lanier	Lanier 5645 - CUPS+Gutenprint v5.2.10
Lanier	Lanier LD015 - CUPS+Gutenprint v5.2.10
Lanier	Lanier LD035 - CUPS+Gutenprint v5.2.10
Lanier	Lanier LD045 - CUPS+Gutenprint v5.2.10
Lanier	Lanier LD060 - CUPS+Gutenprint v5.2.10
Lanier	Lanier LD075 - CUPS+Gutenprint v5.2.10
Lanier	Lanier LD090 - CUPS+Gutenprint v5.2.10
Lanier	Lanier LD0105 - CUPS+Gutenprint v5.2.10
Lanier	Lanier LD115 - CUPS+Gutenprint v5.2.10
Lanier	Lanier LD116 - CUPS+Gutenprint v5.2.10
Lanier	Lanier LD118 - CUPS+Gutenprint v5.2.10
Lanier	Lanier LD118d - CUPS+Gutenprint v5.2.10
Lanier	Lanier LD120 - CUPS+Gutenprint v5.2.10
Lanier	Lanier LD120d - CUPS+Gutenprint v5.2.10
Lanier	Lanier LD122 - CUPS+Gutenprint v5.2.10

Producer	Model
Lanier	Lanier LD127 - CUPS+Gutenprint v5.2.10
Lanier	Lanier LD132 - CUPS+Gutenprint v5.2.10
Lanier	Lanier LD135 - CUPS+Gutenprint v5.2.10
Lanier	Lanier LD145 - CUPS+Gutenprint v5.2.10
Lanier	Lanier LD151 - CUPS+Gutenprint v5.2.10
Lanier	Lanier LD160 - CUPS+Gutenprint v5.2.10
Lanier	Lanier LD175 - CUPS+Gutenprint v5.2.10
Lanier	Lanier LD225 - CUPS+Gutenprint v5.2.10
Lanier	Lanier LD230 - CUPS+Gutenprint v5.2.10
Lanier	Lanier LD235 - CUPS+Gutenprint v5.2.10
Lanier	Lanier LD245 - CUPS+Gutenprint v5.2.10
Lanier	Lanier MP 161/LD016 - CUPS+Gutenprint v5.2.10
Lanier	Lanier MP 1100/LD1100 - CUPS+Gutenprint v5.2.10
Lanier	Lanier MP 1350/LD1135 - CUPS+Gutenprint v5.2.10
Lanier	Lanier MP 1600/LD316 - CUPS+Gutenprint v5.2.10
Lanier	Lanier MP 2000/LD320d - CUPS+Gutenprint v5.2.10
Lanier	Lanier MP 2510/LD325 - CUPS+Gutenprint v5.2.10
Lanier	Lanier MP 2550/LD425 - CUPS+Gutenprint v5.2.10
Lanier	Lanier MP 2550B/LD425B - CUPS+Gutenprint v5.2.10
Lanier	Lanier MP 3010/LD330 - CUPS+Gutenprint v5.2.10
Lanier	Lanier MP 3350/LD433 - CUPS+Gutenprint v5.2.10
Lanier	Lanier MP 3350B/LD433B - CUPS+Gutenprint v5.2.10
Lanier	Lanier MP 3500/LD335 - CUPS+Gutenprint v5.2.10
Lanier	Lanier MP 4000/LD040 - CUPS+Gutenprint v5.2.10
Lanier	Lanier MP 4000B/LD040B - CUPS+Gutenprint v5.2.10
Lanier	Lanier MP 4500/LD345 - CUPS+Gutenprint v5.2.10
Lanier	Lanier MP 5000/LD050 - CUPS+Gutenprint v5.2.10
Lanier	Lanier MP 5000B/LD050B - CUPS+Gutenprint v5.2.10
Lanier	Lanier MP 5500/LD255 - CUPS+Gutenprint v5.2.10
Lanier	Lanier MP 6500/LD265 - CUPS+Gutenprint v5.2.10
Lanier	Lanier MP 7500/LD275 - CUPS+Gutenprint v5.2.10
Lanier	Lanier MP 9000/LD190 - CUPS+Gutenprint v5.2.10
Lanier	Lanier MP2500/LD125 - CUPS+Gutenprint v5.2.10
Lexmark	Lexmark 4076 - CUPS+Gutenprint v5.2.10
Lexmark	Lexmark Optra E - CUPS+Gutenprint v5.2.10
Lexmark	Lexmark Optra E+ - CUPS+Gutenprint v5.2.10
Lexmark	Lexmark Optra E220 - CUPS+Gutenprint v5.2.10
Lexmark	Lexmark Optra E321 - CUPS+Gutenprint v5.2.10
Lexmark	Lexmark Optra E323 - CUPS+Gutenprint v5.2.10
Lexmark	Lexmark Valuewriter 300 - CUPS+Gutenprint v5.2.10
Lexmark	Lexmark X73 - CUPS+Gutenprint v5.2.10
Lexmark	Lexmark Z42 - CUPS+Gutenprint v5.2.10
Lexmark	Lexmark Z43 - CUPS+Gutenprint v5.2.10
Lexmark	Lexmark Z52 - CUPS+Gutenprint v5.2.10
Lexmark	Lexmark Z53 - CUPS+Gutenprint v5.2.10
Minolta	Minolta PagePro 6 - CUPS+Gutenprint v5.2.10

Producer	Model
Minolta	Minolta PagePro 6e - CUPS+Gutenprint v5.2.10
Minolta	Minolta PagePro 6ex - CUPS+Gutenprint v5.2.10
Minolta	Minolta PagePro 8 - CUPS+Gutenprint v5.2.10
Minolta	Minolta PagePro 8L - CUPS+Gutenprint v5.2.10
Minolta	Minolta PagePro 1100 - CUPS+Gutenprint v5.2.10
Mitsubishi	Mitsubishi CP-3020D - CUPS+Gutenprint v5.2.10
Mitsubishi	Mitsubishi CP-3020DA - CUPS+Gutenprint v5.2.10
Mitsubishi	Mitsubishi CP-3020DAE - CUPS+Gutenprint v5.2.10
Mitsubishi	Mitsubishi CP-3020DE - CUPS+Gutenprint v5.2.10
Mitsubishi	Mitsubishi CP-3020DU - CUPS+Gutenprint v5.2.10
Mitsubishi	Mitsubishi CP-3800DW - CUPS+Gutenprint v5.2.10
Mitsubishi	Mitsubishi CP-9550D - CUPS+Gutenprint v5.2.10
Mitsubishi	Mitsubishi CP-9550DW - CUPS+Gutenprint v5.2.10
Mitsubishi	Mitsubishi CP-9810D - CUPS+Gutenprint v5.2.10
Mitsubishi	Mitsubishi CP-9810DW - CUPS+Gutenprint v5.2.10
Mitsubishi	Mitsubishi CP-D70DW - CUPS+Gutenprint v5.2.10
Mitsubishi	Mitsubishi CP-D707DW - CUPS+Gutenprint v5.2.10
Mitsubishi	Mitsubishi CP-K60DW - CUPS+Gutenprint v5.2.10
NEC	NEC SuperScript 660i - CUPS+Gutenprint v5.2.10
NEC	NEC SuperScript 860 - CUPS+Gutenprint v5.2.10
NEC	NEC SuperScript 870 - CUPS+Gutenprint v5.2.10
NEC	NEC SuperScript 1260 - CUPS+Gutenprint v5.2.10
NEC	NEC SuperScript 1400 - CUPS+Gutenprint v5.2.10
NEC	NEC SuperScript 1800 - CUPS+Gutenprint v5.2.10
NRG	NRG 2205/2238/2212 - CUPS+Gutenprint v5.2.10
NRG	NRG 2705/2738/2712 - CUPS+Gutenprint v5.2.10
NRG	NRG 3205/3238/3212 - CUPS+Gutenprint v5.2.10
NRG	NRG 3525/3508/3502 - CUPS+Gutenprint v5.2.10
NRG	NRG 3545/3518/3532 - CUPS+Gutenprint v5.2.10
NRG	NRG 4525/4508/4502 - CUPS+Gutenprint v5.2.10
NRG	NRG 4545/4518/4532 - CUPS+Gutenprint v5.2.10
NRG	NRG 6002/6005/6008 - CUPS+Gutenprint v5.2.10
NRG	NRG 7502/7505/7508 - CUPS+Gutenprint v5.2.10
NRG	NRG 9005/9008/9002 - CUPS+Gutenprint v5.2.10
NRG	NRG 10515/10518/10512 - CUPS+Gutenprint v5.2.10
NRG	NRG DSm415 - CUPS+Gutenprint v5.2.10
NRG	NRG DSm615 - CUPS+Gutenprint v5.2.10
NRG	NRG DSm616 - CUPS+Gutenprint v5.2.10
NRG	NRG DSm618 - CUPS+Gutenprint v5.2.10
NRG	NRG DSm618d - CUPS+Gutenprint v5.2.10
NRG	NRG DSm620 - CUPS+Gutenprint v5.2.10
NRG	NRG DSm620d - CUPS+Gutenprint v5.2.10
NRG	NRG DSm622 - CUPS+Gutenprint v5.2.10
NRG	NRG DSm627 - CUPS+Gutenprint v5.2.10
NRG	NRG DSm632 - CUPS+Gutenprint v5.2.10
NRG	NRG DSm635 - CUPS+Gutenprint v5.2.10

Producer	Model
NRG	NRG DSm645 - CUPS+Gutenprint v5.2.10
NRG	NRG DSm651 - CUPS+Gutenprint v5.2.10
NRG	NRG DSm660 - CUPS+Gutenprint v5.2.10
NRG	NRG DSm675 - CUPS+Gutenprint v5.2.10
NRG	NRG DSm725 - CUPS+Gutenprint v5.2.10
NRG	NRG DSm730 - CUPS+Gutenprint v5.2.10
NRG	NRG DSm735 - CUPS+Gutenprint v5.2.10
NRG	NRG DSm745 - CUPS+Gutenprint v5.2.10
NRG	NRG MP 161 - CUPS+Gutenprint v5.2.10
NRG	NRG MP 1100 - CUPS+Gutenprint v5.2.10
NRG	NRG MP 1350 - CUPS+Gutenprint v5.2.10
NRG	NRG MP 1600 - CUPS+Gutenprint v5.2.10
NRG	NRG MP 2000 - CUPS+Gutenprint v5.2.10
NRG	NRG MP 2500 - CUPS+Gutenprint v5.2.10
NRG	NRG MP 2510 - CUPS+Gutenprint v5.2.10
NRG	NRG MP 2550 - CUPS+Gutenprint v5.2.10
NRG	NRG MP 2550B - CUPS+Gutenprint v5.2.10
NRG	NRG MP 3010 - CUPS+Gutenprint v5.2.10
NRG	NRG MP 3350 - CUPS+Gutenprint v5.2.10
NRG	NRG MP 3350B - CUPS+Gutenprint v5.2.10
NRG	NRG MP 3500 - CUPS+Gutenprint v5.2.10
NRG	NRG MP 4000 - CUPS+Gutenprint v5.2.10
NRG	NRG MP 4000B - CUPS+Gutenprint v5.2.10
NRG	NRG MP 4500 - CUPS+Gutenprint v5.2.10
NRG	NRG MP 5000 - CUPS+Gutenprint v5.2.10
NRG	NRG MP 5000B - CUPS+Gutenprint v5.2.10
NRG	NRG MP 5500 - CUPS+Gutenprint v5.2.10
NRG	NRG MP 6500 - CUPS+Gutenprint v5.2.10
NRG	NRG MP 7500 - CUPS+Gutenprint v5.2.10
NRG	NRG MP 9000 - CUPS+Gutenprint v5.2.10
Oki	Oki 9-Pin Series
Oki	Oki 24-Pin Series
Oki	Oki B401d - CUPS+Gutenprint v5.2.10
Oki	Oki B4350 - CUPS+Gutenprint v5.2.10
Oki	Oki Okipage 6e - CUPS+Gutenprint v5.2.10
Oki	Oki Okipage 6ex - CUPS+Gutenprint v5.2.10
Oki	Oki Okipage 8p - CUPS+Gutenprint v5.2.10
Oki	Oki Okipage 10e - CUPS+Gutenprint v5.2.10
Oki	Oki Okipage 10ex - CUPS+Gutenprint v5.2.10
Oki	Oki Okipage 14ex - CUPS+Gutenprint v5.2.10
Oki	Oki OL400 - CUPS+Gutenprint v5.2.10
Oki	Oki OL400e - CUPS+Gutenprint v5.2.10
Oki	Oki OL400ex - CUPS+Gutenprint v5.2.10
Oki	Oki OL410e - CUPS+Gutenprint v5.2.10
Oki	Oki OL600e - CUPS+Gutenprint v5.2.10
Oki	Oki OL610e/S - CUPS+Gutenprint v5.2.10

Producer	Model
Oki	Oki OL800 - CUPS+Gutenprint v5.2.10
Oki	Oki OL810ex - CUPS+Gutenprint v5.2.10
Oki	Oki Super 6e - CUPS+Gutenprint v5.2.10
Olivetti	Olivetti JP350S - CUPS+Gutenprint v5.2.10
Olivetti	Olivetti PG 306 - CUPS+Gutenprint v5.2.10
Olympus	Olympus P-10 - CUPS+Gutenprint v5.2.10
Olympus	Olympus P-11 - CUPS+Gutenprint v5.2.10
Olympus	Olympus P-200 - CUPS+Gutenprint v5.2.10
Olympus	Olympus P-300 - CUPS+Gutenprint v5.2.10
Olympus	Olympus P-300E - CUPS+Gutenprint v5.2.10
Olympus	Olympus P-300U - CUPS+Gutenprint v5.2.10
Olympus	Olympus P-330E - CUPS+Gutenprint v5.2.10
Olympus	Olympus P-330NE - CUPS+Gutenprint v5.2.10
Olympus	Olympus P-400 - CUPS+Gutenprint v5.2.10
Olympus	Olympus P-440 - CUPS+Gutenprint v5.2.10
Olympus	Olympus P-S100 - CUPS+Gutenprint v5.2.10
Panasonic	Panasonic KX-P4410 - CUPS+Gutenprint v5.2.10
Panasonic	Panasonic KX-P4450 - CUPS+Gutenprint v5.2.10
Panasonic	Panasonic KX-P6150 - CUPS+Gutenprint v5.2.10
Panasonic	Panasonic KX-P6500 - CUPS+Gutenprint v5.2.10
PCPI	PCPI 1030 - CUPS+Gutenprint v5.2.10
Raven	Raven LP-410 - CUPS+Gutenprint v5.2.10
Raw	Raw Queue
Ricoh	Ricoh Aficio 220 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio 401 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio 700 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio 1022 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio 1027 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio 1032 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio 1035 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio 1045 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio 1060 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio 1075 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio 1515 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio 2015 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio 2016 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio 2018 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio 2018D - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio 2020 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio 2020D - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio 2022 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio 2027 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio 2032 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio 2035 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio 2035e - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio 2045 - CUPS+Gutenprint v5.2.10

Producer	Model
Ricoh	Ricoh Aficio 2045e - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio 2051 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio 2060 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio 2075 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio 2090 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio 2105 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio 3025 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio 3030 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio 3035 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio 3045 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio MP 161 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio MP 1100 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio MP 1350 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio MP 1600 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio MP 2000 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio MP 2500 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio MP 2510 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio MP 2550 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio MP 2550B - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio MP 3010 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio MP 3350 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio MP 3350B - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio MP 3500 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio MP 4000 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio MP 4000B - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio MP 4500 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio MP 5000 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio MP 5000B - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio MP 5500 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio MP 6500 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio MP 7500 - CUPS+Gutenprint v5.2.10
Ricoh	Ricoh Aficio MP 9000 - CUPS+Gutenprint v5.2.10
Samsung	Samsung ML-85 - CUPS+Gutenprint v5.2.10
Samsung	Samsung ML-1250 - CUPS+Gutenprint v5.2.10
Samsung	Samsung ML-1450 - CUPS+Gutenprint v5.2.10
Samsung	Samsung ML-1450PS - CUPS+Gutenprint v5.2.10
Samsung	Samsung ML-1650 - CUPS+Gutenprint v5.2.10
Samsung	Samsung ML-1651N - CUPS+Gutenprint v5.2.10
Samsung	Samsung ML-1750 - CUPS+Gutenprint v5.2.10
Samsung	Samsung ML-2150 - CUPS+Gutenprint v5.2.10
Samsung	Samsung ML-2150PS - CUPS+Gutenprint v5.2.10
Samsung	Samsung ML-2151N - CUPS+Gutenprint v5.2.10
Samsung	Samsung ML-2151NPS - CUPS+Gutenprint v5.2.10
Samsung	Samsung ML-2152W - CUPS+Gutenprint v5.2.10
Samsung	Samsung ML-2152WPS - CUPS+Gutenprint v5.2.10
Samsung	Samsung ML-2250 - CUPS+Gutenprint v5.2.10



Producer	Model
Samsung	Samsung ML-2550 - CUPS+Gutenprint v5.2.10
Samsung	Samsung ML-2551N - CUPS+Gutenprint v5.2.10
Samsung	Samsung ML-2552W - CUPS+Gutenprint v5.2.10
Samsung	Samsung ML-4600 - CUPS+Gutenprint v5.2.10
Samsung	Samsung ML-5000a - CUPS+Gutenprint v5.2.10
Samsung	Samsung ML-6000 - CUPS+Gutenprint v5.2.10
Samsung	Samsung ML-6100 - CUPS+Gutenprint v5.2.10
Samsung	Samsung ML-7000 - CUPS+Gutenprint v5.2.10
Samsung	Samsung ML-7000N - CUPS+Gutenprint v5.2.10
Samsung	Samsung ML-7000P - CUPS+Gutenprint v5.2.10
Samsung	Samsung ML-7050 - CUPS+Gutenprint v5.2.10
Samsung	Samsung ML-7300 - CUPS+Gutenprint v5.2.10
Samsung	Samsung ML-7300N - CUPS+Gutenprint v5.2.10
Samsung	Samsung QL-5100A - CUPS+Gutenprint v5.2.10
Samsung	Samsung QL-6050 - CUPS+Gutenprint v5.2.10
Savin	Savin 816 - CUPS+Gutenprint v5.2.10
Savin	Savin 2522 - CUPS+Gutenprint v5.2.10
Savin	Savin 2527 - CUPS+Gutenprint v5.2.10
Savin	Savin 2532 - CUPS+Gutenprint v5.2.10
Savin	Savin 2535/2235 - CUPS+Gutenprint v5.2.10
Savin	Savin 2545/2245 - CUPS+Gutenprint v5.2.10
Savin	Savin 2560 - CUPS+Gutenprint v5.2.10
Savin	Savin 2575 - CUPS+Gutenprint v5.2.10
Savin	Savin 3515 - CUPS+Gutenprint v5.2.10
Savin	Savin 4015 - CUPS+Gutenprint v5.2.10
Savin	Savin 4018 - CUPS+Gutenprint v5.2.10
Savin	Savin 4018d - CUPS+Gutenprint v5.2.10
Savin	Savin 4022 - CUPS+Gutenprint v5.2.10
Savin	Savin 4027 - CUPS+Gutenprint v5.2.10
Savin	Savin 4035/4135g - CUPS+Gutenprint v5.2.10
Savin	Savin 4035e/4135eG - CUPS+Gutenprint v5.2.10
Savin	Savin 4045/4145g - CUPS+Gutenprint v5.2.10
Savin	Savin 4045e/4145eG - CUPS+Gutenprint v5.2.10
Savin	Savin 4051 - CUPS+Gutenprint v5.2.10
Savin	Savin 4060 - CUPS+Gutenprint v5.2.10
Savin	Savin 4075 - CUPS+Gutenprint v5.2.10
Savin	Savin 4090 - CUPS+Gutenprint v5.2.10
Savin	Savin 7025 - CUPS+Gutenprint v5.2.10
Savin	Savin 8016 - CUPS+Gutenprint v5.2.10
Savin	Savin 8020 - CUPS+Gutenprint v5.2.10
Savin	Savin 8020d - CUPS+Gutenprint v5.2.10
Savin	Savin 8025 - CUPS+Gutenprint v5.2.10
Savin	Savin 8025e - CUPS+Gutenprint v5.2.10
Savin	Savin 8030 - CUPS+Gutenprint v5.2.10
Savin	Savin 8030e - CUPS+Gutenprint v5.2.10
Savin	Savin 8035/8035g - CUPS+Gutenprint v5.2.10

Producer	Model
Savin	Savin 8035e - CUPS+Gutenprint v5.2.10
Savin	Savin 8045/8045g - CUPS+Gutenprint v5.2.10
Savin	Savin 8045e - CUPS+Gutenprint v5.2.10
Savin	Savin 8055 - CUPS+Gutenprint v5.2.10
Savin	Savin 8065 - CUPS+Gutenprint v5.2.10
Savin	Savin 8075 - CUPS+Gutenprint v5.2.10
Savin	Savin 8090 - CUPS+Gutenprint v5.2.10
Savin	Savin 8110 - CUPS+Gutenprint v5.2.10
Savin	Savin 8135 - CUPS+Gutenprint v5.2.10
Savin	Savin 9016 - CUPS+Gutenprint v5.2.10
Savin	Savin 9021d - CUPS+Gutenprint v5.2.10
Savin	Savin 9025 - CUPS+Gutenprint v5.2.10
Savin	Savin 9025b - CUPS+Gutenprint v5.2.10
Savin	Savin 9033 - CUPS+Gutenprint v5.2.10
Savin	Savin 9033b - CUPS+Gutenprint v5.2.10
Savin	Savin 9040 - CUPS+Gutenprint v5.2.10
Savin	Savin 9040b - CUPS+Gutenprint v5.2.10
Savin	Savin 9050 - CUPS+Gutenprint v5.2.10
Savin	Savin 9050b - CUPS+Gutenprint v5.2.10
Savin	Savin 40105 - CUPS+Gutenprint v5.2.10
Seiko	Seiko SpeedJET 200 - CUPS+Gutenprint v5.2.10
Sharp	Sharp AR-161 - CUPS+Gutenprint v5.2.10
Sharp	Sharp AR-M257 - CUPS+Gutenprint v5.2.10
Shinko	Shinko CHC-S2145 - CUPS+Gutenprint v5.2.10
Shinko	Shinko CHC-S9045 - CUPS+Gutenprint v5.2.10
Sinfonia	Sinfonia CHC-S2145 - CUPS+Gutenprint v5.2.10
Sony	Sony DPP-EX5 - CUPS+Gutenprint v5.2.10
Sony	Sony DPP-EX7 - CUPS+Gutenprint v5.2.10
Sony	Sony IJP-V100 - CUPS+Gutenprint v5.2.10
Sony	Sony UP-DP10 - CUPS+Gutenprint v5.2.10
Sony	Sony UP-DR100 - CUPS+Gutenprint v5.2.10
Sony	Sony UP-DR150 - CUPS+Gutenprint v5.2.10
Sony	Sony UP-DR200 - CUPS+Gutenprint v5.2.10
Star	Star LaserPrinter 8 - CUPS+Gutenprint v5.2.10
Star	Star LS-04 - CUPS+Gutenprint v5.2.10
Tally	Tally MT908 - CUPS+Gutenprint v5.2.10
Tektronix	Tektronix Phaser 750DP - CUPS+Gutenprint v5.2.10
Tektronix	Tektronix Phaser 750DX - CUPS+Gutenprint v5.2.10
Tektronix	Tektronix Phaser 750N - CUPS+Gutenprint v5.2.10
Tektronix	Tektronix Phaser 750P - CUPS+Gutenprint v5.2.10
Xerox	Xerox Able 1406 - CUPS+Gutenprint v5.2.10
Xerox	Xerox Document Centre 400 - CUPS+Gutenprint v5.2.10
Xerox	Xerox DocuPrint 4508 - CUPS+Gutenprint v5.2.10
Xerox	Xerox DocuPrint C20 - CUPS+Gutenprint v5.2.10
Xerox	Xerox DocuPrint N4512 - CUPS+Gutenprint v5.2.10
Xerox	Xerox DocuPrint N4512PS - CUPS+Gutenprint v5.2.10

Producer	Model
Xerox	Xerox DocuPrint P8e - CUPS+Gutenprint v5.2.10
Xerox	Xerox DocuPrint P12 - CUPS+Gutenprint v5.2.10
Xerox	Xerox DocuPrint P1202 - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 2135 - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 4400B - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 4400DT - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 4400DX - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 4400N - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 4500B - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 4500DT - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 4500DX - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 4500N - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 4510B - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 4510DT - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 4510DX - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 4510N - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 5500B - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 5500DN - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 5500DT - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 5500DX - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 5500N - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 6130N - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 6180DN - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 6180MFP-D - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 6200B - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 6200DP - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 6200DX - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 6200N - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 6250B - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 6250DP - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 6250DT - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 6250DX - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 6250N - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 6300DN - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 6300N - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 6350DP - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 6350DT - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 6350DX - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 6360DN - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 6360DX - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 7300B - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 7300DN - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 7300DT - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 7300DX - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 7300N - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 7400DN - CUPS+Gutenprint v5.2.10

Producer	Model
Xerox	Xerox Phaser 7400DT - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 7400DX - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 7400DXF - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 7400N - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 7700DN - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 7700DX - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 7700GX - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 7750B - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 7750DN - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 7750DXF - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 7750GX - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 7760DN - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 7760DX - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 7760GX - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 8400B - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 8400BD - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 8400DP - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 8400DX - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 8400N - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 8500DN - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 8500N - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 8550DP - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 8550DT - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 8550DX - CUPS+Gutenprint v5.2.10
Xerox	Xerox Phaser 8560DN - CUPS+Gutenprint v5.2.10
Xerox	Xerox WorkCentre 7345 - CUPS+Gutenprint v5.2.10
Xerox	Xerox WorkCentre M118 - CUPS+Gutenprint v5.2.10
Zebra	Zebra CPCL Label Printer
Zebra	Zebra EPL1 Label Printer
Zebra	Zebra EPL2 Label Printer
Zebra	Zebra ZPL Label Printer

# HEIDENHAIN

## DR. JOHANNES HEIDENHAIN GmbH

Dr.-Johannes-Heidenhain-Straße 5

83301 Traunreut, Germany

☎ +49 8669 31-0

☎ +49 8669 32-5061

E-mail: info@heidenhain.de

**Technical support** ☎ +49 8669 32-1000

**Measuring systems** ☎ +49 8669 31-3104

E-mail: service.ms-support@heidenhain.de

**TNC support** ☎ +49 8669 31-3101

E-mail: service.nc-support@heidenhain.de

**NC programming** ☎ +49 8669 31-3103

E-mail: service.nc-pgm@heidenhain.de

**PLC programming** ☎ +49 8669 31-3102

E-mail: service.plc@heidenhain.de

**Lathe controls** ☎ +49 8669 31-3105

E-mail: service.lathe-support@heidenhain.de

[www.heidenhain.de](http://www.heidenhain.de)